



INSTALLATION INSTRUCTIONS

HWC8 V-Series™ Models

This manual must be left with the homeowner for future reference.



This is a safety alert symbol and should never be ignored. When you see this symbol on labels or in manuals, be alert to the potential for personal injury or death.

WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a licensed professional installer (or equivalent), service agency or the gas supplier.

WARNING

Do not store combustible materials near the furnace or warm air ducts. The material may ignite by spontaneous combustion creating a fire hazard.

WARNING

These units are not approved for mobile home applications. Such use could result in property damage, personal injury, or death.

CAUTION

If these instructions are not followed exactly, a fire or explosion may result causing property damage, personal injury, or loss of life.

Table of Contents

Unit Dimensions	2
Installation	3
Electrical Connections	7
Start-Up	11
Operation	11
Maintenance	12
Wiring Diagrams	16

WARNING

For your safety, do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. Such actions could result in property damage, personal injury, or death.

CAUTION

Installation shall be made in accordance with the requirements of the local utility and other authorities having jurisdiction, or with the National Fuel Gas Code, ANSI Z223.1 (latest edition) and the National Electrical Code. Any alteration of internal wiring will void certification and warranties.




Manufactured By
Allied Air Enterprises LLC
A Lennox International, Inc. Company
215 Metropolitan Drive
West Columbia, SC 29170



(P) 507388-03

Save these instructions for future reference

Unit Dimensions



Installation

General

These instructions must be hung on or near the furnace in a conspicuous place.

The HWC8 V-Series™ units are self-contained, gas-fired heating with electric cooling models. The unit design has been certified by Intertek Testing Services for compliance with the latest edition of the American National Standard ANSI Z21.47 for direct vent central furnaces. The HWC8 models are certified to be in compliance with the latest edition of A.H.R.I. Standard 210/240. All models are design certified for heating operation when fired with natural or propane gas.

These installation instructions are intended as a general guide only, for use by an experienced, qualified contractor.

Inspection

The unit is shipped in one package, completely assembled and wired. The Evaporator drain tubing is in the cooling compartment behind the filter access panel.

If any damage is found, proper notation should be made on the carrier's freight bill. Damage claims should be filed with the carrier as quickly as possible.

Check the rating plate to confirm heating and cooling capacities. The unit should be operated only with the type of gas and electrical supply noted on the rating plate.

WARNING

In the State of Massachusetts:

This product must be installed by a licensed Plumber or Gas Fitter. When flexible connectors are used, the maximum length shall not exceed 36". When lever-type gas shutoffs are used, they shall be T-handle type.

NOTE: Remove the chassis hold down shipping bracket before installation. These brackets are located on the outdoor side of the unit below the louver panels.

Location

The design is certified for indoor installation only. The interior portions of the unit may be surrounded by a closet with minimum clearances to combustible material held to 0" sides, 2" top, and 1" front and plenum. Adequate clearance must be provided to install gas line union and manual shutoff valve as well as providing accessibility for field wiring. Do not install directly on carpeting, tile, or other combustible material other than wood flooring.

The grille side of the unit may be flush with, or extend beyond, the face of the exterior wall, but should not be recessed more than 2" from the face of the building and should not be obstructed with trees, landscape materials, or building structure.

There is no minimum clearance required on locating the unit to an interior corner of a building.

If the unit is to be enclosed, provisions should be made allowing access to the indoor side of the unit for changing filters and for inspection. At least 29" of unobstructed space should be provided in front of the indoor side, whether enclosed or not, to permit removal of the cooling chassis should repairs or inspection be required.

If the unit is installed in a residential garage, it must be located or protected to avoid physical damage by vehicles. Unit must be installed so the burners and ignition source are not less than 18" (457 mm) above the floor. This unit must be installed so that no electrical components are exposed to water.

This appliance should be installed in a location such that the vent outlet is located in the following manner:

1. Distances to windows that open, building openings, or public walkways should be consistent with the National Fuel Gas Code Z223.1.
2. For U.S. installations, the vent system shall terminate a minimum horizontal clearance of 4' from electric meters, regulators, and relief equipment.
3. Flue products will not cause degradation to building materials.

This furnace design is not listed for installation in mobile homes, recreational vehicles, or outdoors.

Use of Furnace as a Construction Heater

Allied Air does not recommended the use of these units as a construction heater during any phase of construction. Very low return air temperature, harmful vapors and operation of the unit with clogged or misplaced filters will damage the unit.

Units may be used for heating of buildings or structures under construction, if the following conditions are met:

- The unit must be permanently installed per these installation instructions.
- A room thermostat must control the furnace. The use of fixed jumpers that will provide continuous heating is not allowed.
- The return air duct must be provided and sealed to the furnace.
- Return air temperature range between 60°F (16°C) and 80°F (27°C) must be maintained.

- Air filters must be installed in the system and must be maintained during construction.
- Air filters must be replaced upon construction completion.
- The input rate and temperature rise must be set per the furnace rating plate.
- One hundred percent (100%) outdoor air must be provided for combustion air requirements during construction.
- The furnace heat exchanger, components, duct system, air filters and evaporator coils must be thoroughly cleaned following final construction clean-up.
- All furnace operating conditions (including ignition, input rate, temperature rise and venting) must be verified according to these installation instructions.

Installing With a Wall Sleeve

Refer to the installation instructions packed with the wall sleeve and Figure 1 for guidance in assembly and mounting using a wall sleeve.

Make sure the gaskets attached to the sleeve are not damaged.

Seal the space between the wall sleeve and the building opening with non-hardening caulking compound. The seal must be weather-tight to prevent entrance of moisture and water into the building.

Assure that the unit is completely seated against the gaskets on the wall sleeve.

CAUTION

The sleeve is not intended as the sole support for the unit. An additional support must be provided near the return opening on the unit for adequate support. The use of vibration isolation material between the unit and the support is recommended.

Installing Without a Wall Sleeve

Refer to the following directions and Figure 1 for guidance in installing the unit without a wall sleeve:

1. Measure the size of the unit and provide an opening in an outside wall that will accept the unit. Local ordinances may require a steel lintel to support the wall above the opening. The opening must be square in all four corners.
2. Position the unit so that the grilles on the outside face of the unit are flush or extend beyond the face of the exterior wall, but not recessed more than 2" from the face of the building. Provide a support under the unit, inside the building. Make sure that the inside support does not block the return air. The unit should be installed level or pitched slightly to the outside of the building so that rain water will drain away.
3. Seal the space between the unit and building opening using a non-hardening caulking compound. The seal must be weather-tight to prevent entrance of moisture and water into the building. Make sure the drain holes in the base are not plugged with caulking.




Figure 1. HWC Installation

Evaporator Condensate Drain

Install the plastic drain tube (furnished) over the 5/8" O.D. fitting in the center of the Evaporator condensate pan. Connect other end of the drain tube to the open trap (see Figure 2). The plastic drain connection is provided so that it may be disconnected from the permanent drain tubing in the building in the event it becomes necessary to remove the cooling chassis assembly.

The drain line should pitch gradually downward at least 1" per 10' of horizontal run to the open drain trap.

Be certain that the plastic drain tube has free drainage and is not crimped or flattened at any bend.




Figure 2. HWC Evaporator Condensate Drain Installation

WARNING

Insufficient combustion air can cause headaches, nausea, dizziness or asphyxiation. It will also cause excess water in the heat exchanger resulting in rusting and premature heat exchanger failure. Excessive exposure to contaminated combustion air will result in safety and performance related problems. Avoid exposure to the following substances in the combustion air supply:

- Permanent wave solutions
- Chlorinated waxes and cleaners
- Chlorine base swimming pool chemicals
- Water softening chemicals
- De-icing salts or chemicals
- Carbon tetrachloride
- Halogen type refrigerants
- Cleaning solvents (such as perchloroethylene)
- Printing inks, paint removers, varnishes, etc.
- Hydrochloric acid
- Antistatic fabric softeners for clothes dryers
- Masonry acid washing materials

Combustion Air

This unit is a direct - vent furnace which obtains all air needed for combustion from outdoors.

Venting

The venting system is an integral part of the appliance. The venting system must not be modified or added on to.

The unit contains a combustion inducer. The inducer draws the combustion products out of the heat exchanger together with dilution air and forces the mixture from the unit to the outside. No special provisions are required for supplying air for combustion, nor is a chimney required.

The vent outlet must not be altered or extended.

The venting system is designed for proper operation under all weather conditions and for winds up to 31 m.p.h.

Removal of Unit from Common Venting System

When an existing furnace is removed from a common venting system serving other appliances, the venting system is likely to be too large to properly vent the remaining attached appliances. The following test should be conducted with each appliance while the other appliances connected to the common venting system are not in operation.

1. Seal any unused openings in the common venting system.
2. Visually inspect the venting system for proper size and horizontal pitch and determine there is no blockage or restriction, leakage, corrosion, or other deficiencies which could cause an unsafe condition.
3. Insofar as is practical, close all building doors and windows between the space in which the appliances remaining connected to the common venting system are located and other spaces in the building. Turn on clothes dryers and any appliance not connected to the common venting system. Turn on exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan. Close fireplace dampers.
4. Following the lighting instructions, place the unit being inspected in operation. Adjust the thermostat so the appliance will operate continuously.
5. Test for spillage at the draft control relief opening after 5 minutes of main burner operation. Use the flame of a match or candle.
6. Follow the preceding steps for each appliance connected to the common venting system.
7. After it has been determined that each appliance remaining connected to the common venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers, and any other fuel burning appliance to their previous condition of use.

8. If improper venting is observed during any of the above tests, the common venting system must be corrected. See National Fuel Gas Code, ANSI Z223.1 (latest edition) to correct improper operation of common venting system.

Gas Connections

The gas line to the unit should be adequately sized to prevent undue pressure drop and should never be smaller than the manual valve used. Consult the local utility or National Fuel Gas Code for complete details on special requirements in sizing gas piping.

The units supplied for operation with natural gas contain a gas regulator which must be operated with inlet gas pressures specified on the rating plate. If gas line pressure exceeds this figure, an additional high pressure regulator must be installed to reduce this pressure.

Units for operation with propane must be converted with a kit supplied by the manufacturer and require for operation an inlet pressure of 11" W.C. minimum and 13" W.C. maximum. A regulator is also required on the propane tank.

If local codes allow use of a flexible gas connector, a new listed connector must be used. Do not use a connector which has previously serviced another gas appliance.

⚠ CAUTION

If a flexible gas connector is required or allowed by the authority that has jurisdiction, black iron pipe shall be installed at the gas valve and extend outside the furnace cabinet. The flexible connector can then be added between the black iron pipe and the gas supply line.

⚠ IMPORTANT

Compounds used on threaded joints of gas piping must be resistant to the actions of liquefied petroleum gases.

⚠ CAUTION

Never use a flame to check for gas leaks. Explosion causing injury or death may occur.

A manual shutoff valve must be located outside the unit. The use of a union located upstream of the controls is recommended, between the controls, and the manual shutoff valve. This will facilitate removal of controls and manifold. See Figure 3 for recommended placement of the union.

Provide a drip leg in the supply piping located exterior to the unit. Piping connections must be sealed with non-hardening pipe joint compound resistant to propane.

⚠ WARNING

The furnace must be isolated from the gas supply piping system by closing the individual manual shutoff valve during any pressure testing of gas supply piping system at test pressures equal to or less than 1/2 psig or 14" W.C. If the piping system is to be tested at pressures in excess of 1/2 psig, the furnace and its individual shutoff valve must be disconnected from the gas supply piping system. The gas valve supplied with this furnace is rated at 1/2 psig. Any higher pressure may rupture the pressure regulator diaphragm which will cause over-firing of the burners and improper burner operation. This action may produce a high concentration of carbon monoxide which can result in asphyxiation.




Figure 3. Gas Supply Piping

Leak Check

After gas piping is completed, carefully check all piping connections (factory and field installed) for gas leaks. Use a leak detecting solution or other preferred means.

NOTE: *If emergency shutoff is necessary, shut off the main manual gas valve and disconnect the main power to the furnace. The installer should properly label these devices.*

⚠ CAUTION

Some soaps used for leak detection are corrosive to certain metals. Carefully rinse piping thoroughly after leak test has been completed. Do not use matches, candles, flame or other sources of ignition to check for gas leaks.

Electrical Connections

All wiring must be done in accordance with the National Electrical Code, ANSI/NFPA No. 70 (latest edition); or local codes, where they prevail. Any alteration of internal wiring will void certification and warranty.

ELECTROSTATIC DISCHARGE (ESD)

Precautions and Procedures

CAUTION

Electrostatic discharge can affect electronic components. Take precautions during furnace installation and service to protect the furnace's electronic controls. Precautions will help to avoid control exposure to electrostatic discharge by putting the furnace, the control and the technician at the same electrostatic potential. Neutralize electrostatic charge by touching hand and all tools on an unpainted unit surface, such as the gas valve or vestibule panel, before performing any service procedure.

The rating plate indicates the operating voltage, phase, minimum circuit ampacity, maximum fuse size, and minimum voltage. Units must never be installed where voltage exceeds 10% over the voltage indicated on the rating plate.

Units are factory wired for a 230 volt power supply. If power supply is 208 volts, it will be necessary to change a wire connection on unit transformer from 240 volt terminal to 208 volt terminal as shown on the wiring diagram.

Failure of the compressor as a result of operation on improper voltage voids the compressor replacement warranty.

A separate electric line with wire having a temperature rating of 60°C should be run directly from the main supply panel to the leads in the unit. Refer to the rating plate located on the unit for proper fuse or breaker size. Make sure the unit is electrically grounded in accordance with local codes or, in the absence of local codes, with the National Electrical Code, ANSI/NFPA No. 70 (latest edition) for installations in the U.S.

See rating plate for minimum wire ampacity and size wire accordingly.

Exterior Junction Box and Switch

If local codes allow, a field supplied junction box and optional switch may be installed on the top panel to provide an exterior electrical wiring point and disconnect. A suitable junction box cover must be used. If a switch is used it must meet or exceed the electrical specifications shown on the unit rating plate. The junction box, cover, and (if used) switch are standard items that are locally available.

Installing an Exterior Junction Box

1. Remove the two screws that secure the factory-supplied cover over the rear half of the internal junction box. Keep the front cover in place. See Figure 4.
2. Position a 4x4 junction box over the opening as shown in Figure 5. Make sure the junction box is pulled up against the front cover so that there is no gap. Remove a knock-out in the box to allow the unit wiring leads to extend into the bottom of the box. Pull the leads through the knock-out and into the box. Remove a knock-out for the main power supply leads.
3. Secure the junction box to the top panel using screws.
4. Connect the unit wiring leads to the main power supply or the switch as desired. Securely attach the cover to the junction box. When complete, the junction box should be as shown in Figure 6.
5. The rear cover that was removed in Step 1 is not used and may be discarded.




Figure 4.




Figure 5.




Figure 6.

Thermostat

Install the thermostat according to the directions furnished with it. The thermostat must be located on an inside wall where it will not be affected by drafts, sunlight, or any other heat producing appliances. Connect the thermostat wires to the low voltage leads on top of the unit following the wiring diagram attached to the unit. The heat anticipator setting is 0.50 amp.

Air Filter

All indoor return air must be filtered. A permanent-type filter is furnished with the unit, located directly behind the access panel. Removing the panel permits access to the filter. See Figure 3.

If an installation is made in which it is more desirable to mount the filter exterior to the unit, in the return duct work or elsewhere, the permanent filter can be used or replaced with a disposable filter. If a disposable filter is used, refer to the information provided in Table 1 when sizing the disposable filter.

Model Number	Filter Area (sq. in.)
HWC8*12	300
HWC8*18	480
HWC8*24	480

Table 1. Minimum Required Surface Area for Disposable Filters

Supply and Return Duct(s)

Provide duct(s) sized sufficiently to handle the larger of the air volumes for heating or cooling provided by this model.

Connect the supply duct to the top of the unit using canvas connections or other flexible connections to prevent noise transmission into the duct system.

To connect the return duct to the system, use a straight piece of duct 22" wide by 6" deep. Insert the duct into the return opening in the bottom of the unit and flange the duct over the existing flanges around the opening inside the unit. Make sure that all sides of the duct are flanged over to permit removal of the cooling chassis if required. Use a flexible connection to attach the remainder of the return duct. The return duct should be sealed to the unit casing and must terminate outside the space containing the furnace.

Adjustments – Heating Section

Temperature Rise

At time of installation, the temperature rise must be adjusted to be within the range specified on the unit rating plate. See Table 2. Select a lower blower speed to increase rise. Select a higher blower speed to reduce rise.

Pressure Regulator

The gas input must not exceed the figures shown on the rating plate. The unit is equipped for rated inputs with manifold pressures of: 3.5" W.C. for natural gas and 10.5" W.C. for propane.

The manifold pressure can be measured by removing the pipe plug in the automatic gas valve. Connect a water manometer and measure the pressure. See Figure 9.

Only small variations in gas input may be made by adjusting the regulator. **In no case should the final manifold pressure vary more than 0.3" W.C. for natural gas or 0.7" W.C. for propane.**

To adjust the regulator, turn the adjusting screw on the regulator clockwise to increase pressure and input or counterclockwise to decrease pressure and input. See Figure 9.

For natural gas installations, check the burner rate by observing the gas meter (making sure that all other gas appliances are turned off). The test hand on the meter should be timed for at least one revolution. Note the number of seconds for one revolution.

$$\text{BTU/HR Input} = \frac{\text{Cubic Feet per Revolution}}{\text{\# Seconds per Revolution}} \times 3600 \times \text{Heating Value}$$

Adjustments – Cooling Section (HWC models)

No adjustments are required or should be attempted regarding any of the components of the cooling chassis. The chassis should be checked to see that none of the wiring is loose or missing.

Cooling chassis is charged with R410A refrigerant.

Blower

The unit contains a direct-drive, multispeed blower. The proper speeds have been preset at the factory for heating and cooling. Refer to the wiring diagram or Table 2 for recommended heating/cooling speeds for specific models. Direct-drive blower motors are permanently lubricated and do not require oiling.

Limit Control

A fixed temperature limit control is provided which will shut off the gas to the main burners if the unit is overheated for any reason. The control must not be adjusted or relocated.

High Altitude Adjustments (U.S. Installations)

Ratings shown on the rating plate are for elevations up to 2000 feet. For elevations above 2000 feet, ratings should be reduced at a rate of 4% for each 1000' above sea level. Refer to the National Fuel Gas Code Z223.1 (latest edition) for further explanation.

Installation and Operation in Extremely Cold Weather Areas

In areas where extremely cold (below – 20°F) outdoor temperatures can be expected, some additional installation and operating precautions should be taken. The following precautions are taken to prevent possible vent system ice blockage that could result in safety shutdown of the burners:

1. Adjust to the highest achievable temperature rise within the rise and static pressure ranges specified on the rating plate. Depending on specific model, it may be possible to change to a lower heating blower speed tap to get a higher temperature rise. This also increases comfort.
2. Make sure there are no leaks of outside air into the return air system.
3. Keep the outside louver grille as free as possible of any ice that may form and obstruct the flue outlet.

Model	Rise Range (°F)	Mid Rise (°F)	Indoor Blower Speed	Unit Voltage (V)	0.1" w.c.		0.2" w.c.		0.3" w.c.		0.4" w.c.	
					SCFM	Temp Rise (°F)	SCFM	Temp Rise (°F)	SCFM	Temp Rise (°F)	SCFM	Temp Rise (°F)
HWC8N2412P12A	25 - 55	40	TAP 1 (HEAT) *	208 or 230	455	42	415	46	385	50	355	54
			TAP 2 (HEAT)	208 or 230	570	34	540	36	510	38	485	40
			TAP 3 (HEAT)	208 or 230	655	29	625	31	595	32	575	33
			TAP 4 (COOL)	208 or 230	480		460		440		415	
			TAP 5 (COOL)	208 or 230	530		505		485		460	
HWC8N3612P12A	35 - 65	50	TAP 1 (HEAT)	208 or 230	455	63	415	N/A	385	N/A	355	N/A
			TAP 2 (HEAT) *	208 or 230	570	50	540	53	510	56	485	59
			TAP 3 (HEAT)	208 or 230	655	44	625	46	595	48	575	50
			TAP 4 (COOL)	208 or 230	480		460		440		415	
			TAP 5 (COOL)	208 or 230	530		505		485		460	
HWC8N3612P18A	25 - 55	40	TAP 1 (HEAT) *	208 or 230	630	45	600	48	570	50	550	52
			TAP 2 (HEAT)	208 or 230	770	37	740	39	715	40	690	42
			TAP 3 (HEAT)	208 or 230	885	32	855	34	830	35	810	35
			TAP 4 (COOL)	208 or 230	560		540		520		500	
			TAP 5 (COOL)	208 or 230	610		580		560		535	
HWC8N4812P18A	35 - 65	50	TAP 1 (HEAT)	208 or 230	630	61	600	64	570	N/A	550	N/A
			TAP 2 (HEAT) *	208 or 230	770	50	740	52	715	54	690	56
			TAP 3 (HEAT)	208 or 230	885	43	855	45	830	46	810	47
			TAP 4 (COOL)	208 or 230	560		540		520		500	
			TAP 5 (COOL)	208 or 230	610		580		560		535	
HWC8N6012P18A	45 - 75	60	TAP 1 (HEAT)	208 or 230	630	N/A	600	N/A	570	N/A	550	N/A
			TAP 2 (HEAT)	208 or 230	770	61	740	64	715	66	690	68
			TAP 3 (HEAT) *	208 or 230	885	53	855	55	830	57	810	58
			TAP 4 (COOL)	208 or 230	560		540		520		500	
			TAP 5 (COOL)	208 or 230	610		580		560		535	
HWC8N3612P24A	25 - 55	40	TAP 1 (HEAT) *	208 or 230	630	45	600	48	570	50	550	52
			TAP 2 (HEAT)	208 or 230	770	37	740	39	715	40	690	42
			TAP 3 (HEAT)	208 or 230	885	32	855	34	830	35	810	35
			TAP 4 (COOL)	208 or 230	770		750		730		710	
			TAP 5 (COOL)	208 or 230	820		790		770		750	
HWC8N4812P24A	35 - 65	50	TAP 1 (HEAT)	208 or 230	645	44	615	47	590	49	565	51
			TAP 2 (HEAT) *	208 or 230	780	37	755	38	730	39	710	40
			TAP 3 (HEAT)	208 or 230	900	32	875	33	855	34	835	34
			TAP 4 (COOL)	208 or 230	770		750		730		710	
			TAP 5 (COOL)	208 or 230	820		790		770		750	
HWC8N6012P24A	45 - 75	60	TAP 1 (HEAT)	208 or 230	645	59	615	62	590	65	565	N/A
			TAP 2 (HEAT)	208 or 230	780	49	755	51	730	52	710	54
			TAP 3 (HEAT) *	208 or 230	900	43	875	44	855	45	835	46
			TAP 4 (COOL)	208 or 230	770		750		730		710	
			TAP 5 (COOL)	208 or 230	820		790		770		750	

N/A: Do not operate unit in heating mode using this blower speed at this external static pressure. Outside of temperature rise range.

* As shipped speed for heating operation

Table 2. Airflows and Heating Temperature Rises as a Function of External Static Pressure

Start-Up

For Your Safety Read Before Lighting

WARNING

If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury, or loss of life.

CAUTION

This furnace is equipped with a direct ignition control. Do not attempt to manually light the burners.

To Light Main Burners

1. Turn off electrical power to unit.
2. Turn the thermostat to lowest setting.
3. Move the gas valve ON/OFF switch to the "ON" position (Figure 7).
4. Turn on electrical power to the unit.
5. Set the room thermostat to the desired temperature. (If the thermostat "set" temperature is above room temperature after the pre-purge time expires, main burners will light.)




Figure 7. Gas Valve

To Shut Down Main Burners

1. Turn off electrical power to unit.
2. Move the ON/OFF switch to the "OFF" position (Figure 7).

Operation

Operation of the unit is automatic and will provide heating and cooling depending on the setting of the thermostat.

Heating

1. Turn on main power supply.
2. Open manual gas shutoff valve.
3. Set thermostat system to "HEAT".
4. Set thermostat to temperature desired.

Cooling

1. Turn on main power supply.
2. Set thermostat system switch to "COOL".
3. Set thermostat to temperature desired.

Heating Sequence of Operation

1. Thermostat calls for heat.
2. Combustion blower starts and proper air flow is proven by the pressure switch closing.
3. Blower continues to operate for 30 seconds prior to the burners lighting.
4. Ignition control begins spark and opens gas valve. The burners are lit. Ignition is proved through the flame sensor.
5. Circulating air blower starts 30 seconds after the burners light.
6. When the thermostat is satisfied, the burners and combustion blower shut off.
7. Circulating air blower will shut off 120 seconds later.

If the burners should fail to ignite, the ignition control will try to ignite the burners a total of three times. Should the burners fail to ignite within the three trials for ignition, the ignition control will lock out for 1 hour before beginning another ignition cycle. To reset the control, turn the thermostat down or off for 10 seconds and then set to desired setting. At this time, the ignition sequence will try again.

Blower Control

The blower will start approximately 30 seconds after the burners ignite and will stop approximately 120 seconds after the thermostat is satisfied. The time delay is preset at the factory and timing can not be adjusted.

Cooling Sequence of Operation

When the thermostat system switch is set for "COOL", the blower will start 5 seconds after the thermostat calls for cooling and will stop 90 seconds after the thermostat is satisfied.

Continuous Fan Operation

Continuous operation of the air handling blower will be obtained if the thermostat fan switch is set to "ON". With the thermostat fan switch set to "AUTO", the air handling blower will cycle corresponding with the thermostat cycling.

To Shut Down Unit

For temporary or short periods of shutdown, set the thermostat system switch to "OFF". For a prolonged period of shutdown, set the thermostat system switch to "OFF" and turn off the electrical power supply and the gas supply to the unit.

Maintenance

Refer to Figure 8 for heating compartment component layout.

It is recommended that the furnace be inspected annually by a qualified service person.



WARNING

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in dangerous operation, Serious injury, death or property damage.

Improper servicing could result in dangerous operation, Serious injury, death or property damage

- Before servicing, disconnect all electrical power to furnace
- When servicing controls, label all wires prior to disconnecting reconnect wires correctly.
- Any disassembly of components containing flue or vent gases shall be done by a qualified service agency.
- Verify proper operation after servicing.




Figure 8. Component Layout

Burner & Manifold Assembly

To remove the burner & manifold assembly:

1. Disconnect electrical service and turn off gas to the appliance.
2. Loosen the pipe union external to the unit and remove the gas line to the gas valve.
3. Disconnect the orange high voltage spark wire at the ignition control board.
4. Disconnect the white flame sensor wire at the flame sensor on top of the burner assembly.
5. Disconnect the orange and yellow wires at the rollout switch.
6. Disconnect the red and blue wires at the gas valve.
7. Refer to Figure 9. Remove the two screws on the burner assembly that secure it to the mounting brackets. The mounting brackets contain pins to locate the assembly and hold it in place after the screws are removed. The mounting brackets are hidden until the burner assembly is removed.
8. First, carefully pull the burner assembly toward you until it is clear of the locating pins in the mounting brackets.
9. Then move the assembly away from the vest panel.
10. Finally, pull the assembly from the unit.
11. Once the burner assembly is removed, the burners can be cleaned using a bottle brush.
12. For reassembly, follow the above steps in reverse order.

Control Board Mounting Bracket

The control board mounting bracket is designed to be removed to allow component access for some service procedures. The ignition control board and the inducer prover switch are mounted to the bracket.

1. Disconnect electrical service and turn off gas to the appliance.
2. Loosen the two screws securing the control mounting bracket (it is not necessary to completely remove them).




Figure 9. Burner & Manifold Assembly Removal

3. Lift the bracket clear of the screws and carefully lower the bracket and ignition board to the bottom of the compartment.
4. It may be necessary to remove the inducer prover switch tubing at the switch.
5. For reassembly, follow the above steps in reverse order.

Igniter

The igniter can be accessed from the front of the unit without removing any other components. To remove the igniter:

1. Disconnect electrical service and turn off gas to the appliance.
2. Disconnect the orange high voltage spark wire at the ignition control board.
3. Remove the screw and pull the igniter out of the burner assembly.
4. For reassembly, follow the above steps in reverse order.

Rollout Switch

If for any reason the heat exchanger becomes blocked the temperature-sensitive rollout switch located beside the burners will open and the ignition control will turn off the burners. After investigating and correcting the problem, the rollout switch must be manually reset by pressing the button on top of it.

The rollout switch can be accessed from the front of the unit without removing any other components. To remove the rollout switch:

1. Disconnect electrical service and turn off gas to the appliance.
2. Disconnect the orange and yellow wires at the rollout switch.
3. Remove the screw and slip the rollout switch from beneath the lanced tab on the burner assembly.
4. For reassembly, follow the above steps in reverse order.

Flame Sensor

1. Remove the control board mounting bracket as described previously.
2. Remove the screw and pull the flame sensor from the top of burner assembly.
3. For reassembly, follow the above steps in reverse order.

Primary Limit Switch

The primary limit will shut down the unit in case of overheating and automatically resets when temperature falls to an acceptable level. It is not field adjustable

1. Remove the control board mounting bracket as described previously.
2. Disconnect the two orange and yellow wires at the primary limit switch.
3. Remove the three screws securing the primary limit switch to the vest panel.
4. For reassembly, follow the above steps in reverse order.

Inducer Prover Switch

1. Remove the control board mounting bracket as described previously.
2. Disconnect the two purple leads at the inducer prover switch.
3. If the tubing is in place, remove it.
4. Remove the screw securing the switch to the bracket and slip the strap end out of the hole in the bracket.
5. For reassembly, follow the above steps in reverse order.

Burner Orifices

Orifices are threaded into the gas manifold. To remove them:

1. Remove the burner & manifold assembly as described previously.
2. Remove the four screws securing the gas manifold to the burner assembly.
3. Remove the orifices by unscrewing them. Do not use any pipe thread sealant during reassembly.
4. For reassembly, follow the above steps in reverse order.

Combustion Inducer

The combustion inducer can be removed for inspection, replacement, or to access the heat exchanger and flue tube extension for cleaning. To remove the combustion inducer:

1. Remove the control board mounting bracket as described previously.
2. Disconnect the black inducer motor leads.
3. Disconnect the inducer prover switch tubing at the switch.
4. Remove the two screws on the combustion inducer plate.
5. Pull the combustion inducer and plate toward you until it is free of the dilution air box that supports it. Lower the inducer and plate and rotate to pull the assembly out of the compartment.
6. The flue tube extension can be cleaned if necessary. Leave it in place; do not remove it from the unit.
7. For reassembly, follow the above steps in reverse order.

Heat Exchanger

The heat exchanger should be inspected periodically and cleaned if necessary. When cleaning use a stiff brush with a wire handle to remove scale and soot. To access the heat exchanger tubes for cleaning:

1. Remove the burner & manifold assembly as described previously.
2. Remove the combustion inducer as described previously.
3. Remove the four screws securing the dilution air box to the flue collector box.
4. Remove the nine or twelve screws (depending on model) securing the flue collector box to the vest panel.
5. Using the wire brush, brush out the inside of each heat exchanger tube from the burner assembly end and from the flue collector box end.
6. Brush out the inside of the flue collector box.
7. Brush out the inside of the flue tube extension.
8. If soot buildup is excessive, clean the combustion inducer wheel and housing.
9. When brushing is complete, blow all brushed areas with air. Vacuum as needed.
10. For reassembly, follow the above steps in reverse order.

Cooling Chassis

The refrigeration system contained in the cooling chassis normally requires no maintenance since it is a closed, self-contained system. System is charged with R410A refrigerant. Periodic maintenance is limited to:

- Cleaning the air filter. Follow directions noted on the filter and label attached to the access panel.
- Cleaning the condenser coil if covered with any foreign material, lint, leaves, or other obstructions.

If servicing or major repairs are required, the complete chassis can be removed from the unit. To remove the chassis:

1. Shut off the main power supply.
2. Remove filter access panel and panel covering cooling controls.
3. Remove drain hose from the drain pan.
4. Disconnect the plug-in electrical connections.
5. Disconnect two power leads at contactor (leads come from grommet in unit partition).
6. Remove screws from panel directly in front of blower and remove panel. Also remove additional screws located near top edge of control panel.
7. Drape power wires and wire harnesses out of cabinet and tape to upper panel.
8. Slide out the chassis, being careful not to damage any seals or parts. Particular care should be taken to insure wiring is not damaged during removal/reinstallation process. **Tubing is not to be used as a handle.**

To reinstall the chassis, reverse the procedure outlined above. Be sure that the chassis is inserted as far back as it will go before replacing the screws. Side flanges on the chassis must be engaged with sealing strips on the unit sides to prevent water and air leakage. Reconnect the wire harness, reconnect the power leads, and replace both access panels before turning on the main electrical power.




Figure 10. Wiring Diagram - HWC*12,18




Figure 11. Wiring Diagram - HWC*24