



INSTALLATION AND MAINTENANCE INSTRUCTIONS

MHP4 Series Self-Contained Heat Pump



Save these instructions for future reference



This is a safety alert symbol and should never be ignored. When you see this symbol on labels or in manuals, be alert to the potential for personal injury or death.

Installation

WARNING

These units are not approved for mobile home applications. Such use could result in property damage, personal injury, or death.

Table of Contents

Installation	1
Operation	9
Maintenance	11
Accessories	12
Wiring Diagrams	14

WARNING

Improper installation, adjustment, alteration, service, or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information, consult a qualified installer or service agency.

General

These instructions explain the recommended method of installation of the MHP4 electric cooling unit and associated electrical wiring.

This unit is designed and approved for use as a self-contained air-to-air air conditioning system with optional CLIMATE GUARD™ coated coils.

These instructions, and any instructions packaged with mating components and/or accessories, should be carefully read prior to beginning installation. Note particularly any **CAUTIONS** or **WARNINGS** in these instructions and all labels on the units.

These instructions are intended as a general guide only, for use by qualified personnel and do not supersede any national or local codes in any way. Compliance with all local, state, provincial, or national codes pertaining to this type of equipment should be determined prior to installation.

Manufactured By
Allied Air Enterprises LLC
A Lennox International Inc. Company
215 Metropolitan Drive
West Columbia, SC 29170




(P) 507861-01

CAUTION


The installation of this appliance must conform to the requirements of the National Fire Protection Association; the National Electrical Code, ANSI/NFPA No. 70 (latest edition) in the United States; the Canadian Electrical Code Part 1, CSA 22.1 (latest edition) in Canada; and any state or provincial laws or local ordinances. Local authorities having jurisdiction should be consulted before installation is made. Such applicable regulations or requirements take precedence over the general instructions in this manual.

Units that comply with the maximum cabinet leakage 2% of rated airflow requirements of ANSI/ASHRAE 193 (complies with IECC 2015) are identified on the rating plate.



WARNING

Installation and servicing of air conditioning equipment can be hazardous due to internal refrigerant pressure and live electrical components. Only trained and qualified service personnel should install or service this equipment. Installation and service performed by unqualified persons can result in property damage, personal injury, or death.



WARNING

For your safety, do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. Such actions could result in property damage, personal injury, or death.



WARNING

The unit must be installed with approved wall sleeve and grille accessories for safe operation. Improper installations could result in property damage, personal injury, or death.

Inspection

Upon receipt of equipment, carefully inspect it for possible shipping damage. If damage is found, it should be noted on the carrier’s freight bill. Take special care to examine the unit inside the carton if the carton is damaged. File a claim with the transportation company. **If any damages are discovered and reported to the carrier do not install the unit, as claim may be denied.**

Check the unit rating plate to confirm specifications are as ordered.

Limitations

The unit should be installed in accordance with all national and local safety codes.

Limitations of the unit and appropriate accessories must also be observed.

The outdoor fan is designed to operate against no more than .10” w.c. static pressure.

Minimum and maximum operation conditions must be observed to assure maximum system performance with minimum service required. Refer to Table 1 for the application limitations of the unit.

Outdoor Ambient Air Temperature °F		
Minimum DB		Maximum DB
Cool	Cool	Heat
65	115	75

Indoor Ambient Air Temperature °F			
Minimum		Maximum	
DB/WB	DB	DB/WB	DB
Cool	Heat	Cool	Heat
62/57	50	90/72	80

DB = Dry Bulb
WB = Wet Bulb

Table 1. Application Limitations

Location



WARNING

The unit must be installed with approved wall sleeve and grille accessories for safe operation. Improper installations could result in property damage, personal injury, or death.


For information on wall sleeves and grille accessories, see the **Accessories** section.

The design is certified for thru-the-wall or up-to-the wall (inside wall) installation only. The interior portions of the unit may be surrounded by a closet with clearances to combustible material held to 0” at the sides, top, and front of the plenum. All servicing and cleaning of the unit can be performed from the front. If installed in a closet or utility room, provide 25” clearance in front for service if the door to the room is not in line with the front of the unit (see Figure 1). **Accessibility clearances must take precedence over fire protection clearances.**

Clearance to combustible materials is 0" at the side, top, and front of plenum. If accessibility clearances are greater than clearances to combustibles, accessibility clearances take precedence.

The front of the unit must be accessible for service. If the unit is enclosed, providing a door or access panel opposite the front of the unit is the preferred method of providing access. The door or access panel must be at least 30" wide (centered on the unit) and as tall as the unit.


Top View



IMPORTANT

The unit must be installed with approved wall sleeve and grille accessories for safe operation. Improper installations could result in property damage, personal injury, or death.

Side View



Cabinet Height	Minimum Unit Clearance	
	Front*	Sides
44" or 48"	4"	1"
56" or 68"	5"	

* Listed clearance is using front return with no front return duct installed. If a return duct (top or front) is installed, enough clearance must be provided for the drain trap installation.

Figure 1. Minimum Clearances




Figure 2. Wall Sleeve and Louver Kit Installed

The outside of the unit may be flush with the face of the exterior wall, and it should not be obstructed with trees, landscape materials, or building structure. Unit can be installed recessed with appropriate wall sleeve accessories. There is no minimum clearance required on locating the unit to an interior corner of a building.

If the unit is installed in a residential garage, it must be located or protected to avoid physical damage by vehicles. The unit must be installed so that no electrical components are exposed to water.

⚠ CAUTION

This unit must be installed level to allow for proper drainage of the unit base pan and indoor drain pan.

Wall Sleeve and Louver Grille Installation

Refer to installation instructions included with the wall sleeve kit and the louver grille kit along with Figure 2 for guidance in assembling and installing the wall sleeve and louver grille.

⚠ CAUTION

The sleeve is not intended as the sole support for the unit. An additional support must be provided for adequate support (see Figure 2).

Installing and Securing Unit to Wall Sleeve

1. Make sure the gaskets attached to the sleeve are not damaged.
2. Verify divider panel is positioned properly. Refer to Table 2 for wall sleeves that allow for multiple divider panel locations.

	ASLEEVE**-2	ASLEEVE**-5	Orientation of Flange
Model	Two Positions	Three Positions	
MHP4-11-09,12	Lower	Lower	Down
MHP4-11-18			Up
MHP4-11-24, 30	Upper	Middle	
MHP4-11-36	N/A	Upper	

Table 2.

- Place the MHP unit into the wall sleeve. **Lift leading end of unit and walk unit onto the sleeve.** Once in the sleeve, lower the unit into position. This prevents damage to the base pads. Assure that the unit is level and completely seated against the gaskets on the wall sleeve. The unit must be supported by a field supplied base platform.




Figure 3. Positioning Divider Panel

- Use the two installation brackets to secure the unit to the wall sleeve (see Figure 4). The units are shipped with the brackets placed in the return air compartment. Hook each bracket into the front edge of the wall sleeve side. Position the bracket so it can be bent around the front corner of the unit. Remove one of the two screws in that position on the unit. Line up one of the holes in the installation bracket with the screw hole and attach the bracket to the unit with that screw. Make sure to fasten tight enough that the seal is maintained. Trim off excess bracket if applicable.




Figure 4. Securing Unit

CAUTION

Do not screw into the side of the drain pan, or into the indoor coil or heat strip.

- Inspect the fit up of the unit to the wall sleeve. Verify that the gaskets of the wall sleeve make a complete seal to the unit paying particular attention to top and bottom corners of unit to sleeve seal. Caulk if needed.

Ductwork

Ductwork should be designed and sized according to the methods in Manual Q of the Air Conditioning Contractors of America (ACCA).

Check unit air supply outlet for debris before making ductwork connections.

It is recommended that supply and return duct connections at the unit be made with flexible joints. If flexible ducts are used, a 6" sheet metal starter collar is required.

The supply and return air duct systems should be designed for the CFM and static requirements of the job (see Table 3). **They should not be sized to match the dimensions of the duct connections on the unit.** The return duct should be sealed to the unit casing and terminate outside the space containing the unit.

Optional Front Return

As shipped, units are configured for attaching supply and return ductwork to the top of the unit. Return air may be brought in through the optional front return opening. To open the optional front return and close off the top return opening, perform the following steps.

- Rotate knob to release filter access panel and remove panel.
 - For all units except 3-ton models, position filter access panel to close off top return opening. Secure at rear using two sheet metal screws. Secure in front using knob. See Figure 5.
 - For 3-ton models, field fabricate a sheet metal panel to close off the top return opening.
- Seal panel to top of unit with tape or mastic.

NOTE: If ductwork is attached to the optional front return opening, provisions to service unit filter must be provided.




Figure 5. Secure Filter Access Panel

Airflow Performance as a Function of External Static Pressure												
Model	Indoor Blower Speed		0.1 “w.c.”		0.2 “w.c.”		0.3 “w.c.”		0.4 “w.c.”		0.5 “w.c.”	
			SCFM	Watts	SCFM	Watts	SCFM	Watts	SCFM	Watts	SCFM	Watts
*MHP4-11-091*P	TAP 1 (FAN)		365	28	330	31	275	35	225	38	180	41
	TAP 2 (COOL/HP)†		375	28	325	32	275	35	N/A	N/A	N/A	N/A
	TAP 3 (COOL/HP)		N/A	N/A	N/A	N/A	395	54	370	58	330	62
	3 kW	TAP 4 (AUX HEAT)*	515	55	485	58	450	62	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	600	73	570	78	545	84	515	88	475	92
	5 kW	TAP 4 (AUX HEAT)*	570	69	545	73	515	77	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	660	92	635	98	605	104	580	109	550	114
*MHP4-11-121*P	TAP 1 (FAN)		365	28	330	31	275	35	225	38	180	41
	TAP 2 (COOL/HP)†		490	50	460	55	420	59	N/A	N/A	N/A	N/A
	TAP 3 (COOL/HP)		N/A	N/A	555	77	525	82	495	86	460	91
	3 kW	TAP 4 (AUX HEAT)*	515	55	485	58	450	62	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	600	73	570	78	545	84	515	88	475	92
	5 kW	TAP 4 (AUX HEAT)*	570	69	545	73	515	77	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	660	92	635	98	605	104	580	109	550	114
*MHP4-11-181*P	TAP 1 (FAN)		365	32	335	35	280	39	235	42	175	46
	TAP 2 (COOL/HP)†		615	103	590	108	555	112	530	117	500	121
	TAP 3 (COOL/HP)		700	135	670	141	640	146	615	151	590	157
	3 kW	TAP 4 (AUX HEAT)*	615	93	590	97	555	101	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	715	127	685	134	655	140	630	146	600	151
	5 kW	TAP 4 (AUX HEAT)*	665	110	635	114	605	118	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	750	148	725	154	700	160	675	166	650	171
	7 kW	TAP 4 (AUX HEAT)*	725	137	705	144	675	150	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	825	194	800	200	780	205	755	209	725	213
	10 kW	TAP 4 (AUX HEAT)*	750	148	725	154	700	161	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	860	213	832	219	805	224	780	228	750	232
*MHP4-11-241*P	TAP 1 (FAN)		460	43	420	47	380	51	350	54	290	59
	TAP 2 (COOL/HP)†		815	150	785	161	760	165	740	172	715	178
	TAP 3 (COOL/HP)		885	201	860	208	835	213	805	217	785	220
	5 kW	TAP 4 (AUX HEAT)*	800	146	775	152	750	157	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	905	201	880	207	855	212	825	216	800	219
	7 kW	TAP 4 (AUX HEAT)*	855	174	830	179	800	183	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	955	227	930	231	900	235	875	239	850	243
	10 kW	TAP 4 (AUX HEAT)*	855	174	830	179	800	183	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	955	227	930	231	900	235	875	239	850	243
N/A: Do not operate unit using this blower speed at this external static pressure.												
† As shipped speed for Cooling operation. Blower speed must be field adjusted to Speed Tap 3 for higher duct static applications.												
* As shipped speed for Heating operation. Blower speed must be field adjusted to Speed Tap 5 for higher duct static applications.												

Table 3. Blower Performance (208V or 230V)

Airflow Performance as a Function of External Static Pressure												
Model	Indoor Blower Speed		0.1 “w.c.”		0.2 “w.c.”		0.3 “w.c.”		0.4 “w.c.”		0.5 “w.c.”	
			SCFM	Watts	SCFM	Watts	SCFM	Watts	SCFM	Watts	SCFM	Watts
*MHP4-11-301*P	TAP 1 (FAN)		590	43	535	48	430	55	380	60	315	65
	TAP 2 (COOL/HP)†		1040	161	1005	169	970	177	935	185	900	193
	TAP 3 (COOL/HP)		1135	201	1105	211	1070	220	1040	229	1010	237
	5 kW	TAP 4 (AUX HEAT)*	1075	151	1040	159	1005	168	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	1165	181	1135	193	1100	205	1065	216	1025	225
	7 kW	TAP 4 (AUX HEAT)*	1075	151	1040	159	1005	168	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	1165	181	1135	193	1100	205	1065	216	1025	225
	10 kW	TAP 4 (AUX HEAT)*	1075	151	1040	159	1005	168	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	1165	181	1135	193	1100	205	1065	216	1025	225
*MHP4-11-361*P	TAP 1 (FAN)		680	61	630	68	575	74	525	79	460	86
	TAP 2 (COOL/HP)†		1235	260	1200	272	1165	284	1135	295	1100	305
	TAP 3 (COOL/HP)		1315	304	1280	316	1250	330	1215	342	1180	354
	5 kW	TAP 4 (AUX HEAT)*	1240	232	1205	248	1170	262	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	1340	283	1290	300	1260	315	1230	328	1200	338
	7 kW	TAP 4 (AUX HEAT)*	1240	232	1205	248	1170	262	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	1340	283	1290	300	1260	315	1230	328	1200	338
	10 kW	TAP 4 (AUX HEAT)*	1240	232	1205	248	1170	262	N/A	N/A	N/A	N/A
		TAP 5 (AUX HEAT)	1340	283	1290	300	1260	315	1230	328	1200	338
N/A: Do not operate unit using this blower speed at this external static pressure.												
† As shipped speed for Cooling operation. Blower speed must be field adjusted to Speed Tap 3 for higher duct static applications.												
* As shipped speed for Heating operation. Blower speed must be field adjusted to Speed Tap 5 for higher duct static applications.												

Table 3. Blower Performance (208V or 230V)

Air Filter

All indoor return air must be filtered. A washable filter is furnished with the unit, located in the return air compartment. If the optional front return opening is used and a duct is installed, provisions must be made to accommodate filter servicing. If a filter is installed at a separate central return location, then the factory furnished filter must be removed from the unit.

The filter should be cleaned at least three times during each of the heating and cooling seasons, or more frequently if unusual conditions are encountered. To clean the washable filter, shake filter to remove excess dirt and/or use a vacuum cleaner. Wash filter in soap or detergent water and replace after filter is dry. It is not necessary to oil the filter after washing.

The washable filter may be replaced with a disposable filter. Table 4 lists filter sizes that fit the unit.

If an installation is made in which it is more desirable to mount the filter exterior to the unit, in the return duct work or elsewhere, the washable filter can be used or replaced with a disposable filter. If a disposable filter is used, use the information provided in Table 5 when sizing the disposable filter.

Model Number	Filter Size (in.)
MHP4-11-09 *MHP4-11-12*	18 x 20 x 1
MHP4-11-18	20 x 20 x 1
MHP4-11-24 *MHP4-11-30*	22 x 24 x 1
MHP4-11-36	22 x 28 x 1

Table 4. Filter Sizes

Model Number	Filter Area (in ²)
MHP4-11-09 *MHP4-11-12*	265
3MHP4-11-18* 5MHP4-11-18*	310
7MHP4-11-18* 10MHP4-11-18*	360
MHP4-11-24	400
MHP4-11-30	515
MHP4-11-36	600

Table 5. Minimum Required Surface Area for Disposable Filters

Condensate Drain

Provisions must be made to properly drain the indoor and outdoor drain pans of this appliance.

Indoor drain and outdoor drain connection: 3/4" NPT to 3/4" PVC fitting (schedule 40 minimum). Both drains must be trapped as shown in Figure 6. The drain line should pitch gradually downward at least 1" per 10' of horizontal run to an open drain.




Figure 6. Condensate Drain Installation

If local codes require the use of metal condensate lines, do not thread metal fittings into the unit drain pans. Thread a PVC fitting into the unit drain pans and make the field connection to the PVC fitting.

NOTE: MHP units are designed with a redundant drain system to handle condensate without the need for a secondary or emergency drain pan. Should the indoor coil condensate drain system fail, all water is contained within the unit and the flow is directed into the unit base pan. From there it will drain into the condensate riser.

If for some reason the water cannot drain into the main condensate riser, all water is contained in the unit, and the design will allow drainage out through the wall sleeve and louver assembly to the outside of the building.

CAUTION

Use thread sealant on the threaded fittings. Install threaded fittings by hand only. **Do not over torque the fittings.**

Do not thread metal condensate fittings to unit drain pans.

Outdoor Ventilation Air

Units are fitted with a panel that seals the return air compartment at the outdoor air duct. If introduction of outdoor air is desired, installers can replace the factory-installed panel with the provided auxiliary panel by removing screws holding both the factory and auxiliary panels, and then replacing with the auxiliary panel and screw.

NOTE: *If outdoor ventilation air is introduced, the quantity of air and conditions of this air must be accounted for in the load calculations for the unit installation.*

The auxiliary panel includes nine knockouts to configure air flow to installation requirements. Use Table 6 and Figure 7 to determine which knockouts to remove from the auxiliary panel in order to achieve the desired air flow. Use a flat head screw driver to remove the knockouts. Set the factory-installed panel aside for possible future changes.

		Outdoor Ventilation Air (CFM)					
		MHP4-11-09	*MHP4-11-12*	*MHP4-11-18*	*MHP4-11-24*	*MHP4-11-30*	*MHP4-11-36*
Nominal Indoor Airflow		350	475	600	800	1025	1200
Number of Openings	#1 Only	6	11	13	18	20	23
	#1 and #2	10	17	21	24	28	31
	#1 thru #3	17	22	26	32	36	41
	#1 thru #4	23	28	35	41	45	49
	#1 thru #5	31	34	42	50	55	60
	#1 thru #6	35	41	49	57	66	72
	#1 thru #7	41	49	56	68	80	86
	#1 thru #8	46	56	64	78	88	98
	#1 thru #9	50	60	73	90	100	112

Table 6.

WARNING

The location of fresh air capable models must conform to the requirements of National Fire Protection Association NFPA No. 54 in regards to proximity of forced air inlets to flue gas terminals. Improper installation could result in personal injury or death.




Figure 7. Auxiliary and Factory Panel for Outdoor Air Duct

Thermostat

The room thermostat should be located on an inside wall where it will not be subject to drafts, sun exposure, or heat from electrical fixtures or appliances. Follow manufacturer's instructions enclosed with the thermostat for general installation procedures. Color-coded insulated wires (#18 AWG) should be used to connect the thermostat to the unit.

Electrical Connections

All wiring must be done in accordance with the National Electrical Code (NEC), ANSI/NFPA No. 70 (latest edition); Canadian Electrical Code CSA C22.2 Part 1 (latest edition); or local codes, where they prevail. Any alteration of internal wiring will void certification and warranty.

Units are factory wired for a 230 volt power supply. If power supply is 208 volts, it will be necessary to change a wire connection on unit transformer from 240 volt terminal to 208 volt terminal as shown on the wiring diagram.

Use wiring with a temperature limitation of 75°F minimum. Run the 208 or 230 volt, single phase, 60 hertz electric power supply through a fused disconnect switch to the control box of the unit and connect as shown in the unit's wiring diagram.

The unit must be electrically grounded in accordance with local codes or, in the absence of local codes, with the National Electrical Code ANSI/NFPA No. 70 (latest edition) or CSA C22.2 Part 1 (latest edition).

Power supply to the unit must be NEC Class 1 and must comply with all applicable codes. A fused disconnect switch should be field provided for the unit. The switch must be separate from all other circuits. If any of the wire supplied with the unit must be replaced, replacement wire must be of the type shown on the wiring diagram. Electrical wiring must be sized to minimum circuit ampacity marked on the unit. **Use copper conductors only.** Each unit must be wired with a separate branch circuit and be properly fused.

NOTE: Some MHP4 models require two separate power supply circuits. See the unit wiring diagrams and rating plates for specifications.

Operation

Sequence of Operation

Upon initial "power up" to unit, there is a 3-minute time delay to the compressor contactor (R to Y). Any 24V interrupt (R, C) to the defrost control will initiate the 3-minute delay to the contactor.

Cooling

When the thermostat is in the cooling mode, the O circuit is powered which energizes the reversing valve. Upon cooling demand, the thermostat closes circuit R to Y and G. Closing R to Y closes the unit contactor, starting the compressor and outdoor fan, and signaling the indoor blower to run at cooling speed. Upon satisfying cooling demand, the thermostat will open the above circuits and open the main contactor, stopping the compressor and outdoor fan. The unit is equipped with a blower OFF delay; the blower will continue to operate for a fixed 90 seconds after the thermostat is satisfied.

Heating

Upon heating demand, the thermostat closes circuit R to Y, which closes the unit contactor, starting the compressor and outdoor fan. The reversing valve is not energized in the heating mode. The Y signal from the thermostat brings the indoor blower on at heat pump speed. The second stage of the thermostat closes circuit R to W, which closes the unit sequencers, bringing the auxiliary electric heat on. The W signal from the thermostat brings the indoor blower on at electric heat speed. Upon satisfying heating demand, the thermostat opens the above circuits and stops unit operation.

The unit is equipped with a blower OFF delay; the blower will continue to operate for a fixed 90 seconds (heat pump) or 120 seconds (electric heat) after the thermostat is satisfied.

NOTE: The 7.2 and 10 kW heats strips offer a W1 and W2 thermostat connection. Taking advantage of the two heat strip circuits requires a 3-stage thermostat (Y for heat pump, W1 for electric heat stage 1, and W2 for electric

heat stage 2). If a 2-stage thermostat is used, “pigtail” W1 and W2 wires together when connecting the thermostat wires at the unit.

Defrost Cycle

If the outdoor ambient conditions are such that frost forms on the outdoor coil, the defrost control monitors the need for, initiates, and terminates defrost cycles as necessary to maintain system performance. The defrost control is time/temperature initiated and temperature terminated with a maximum defrost time (time-out) of 14 minutes. Time between defrost cycles is preset at 90-minute intervals at the factory, but can be field adjusted between 30, 60, or 90 minutes. To field adjust time between defrost cycles, place defrost time plug in the proper position (see Figure 9).




Figure 8. Defrost Control




Figure 9. Defrost Interval Timing Jumper

Defrost control will initiate a defrost cycle if the time period has elapsed and the defrost sensor sees a temperature below freezing. At the start of a defrost cycle, the defrost control will energize the reversing valve solenoid, shifting the reversing valve and de-energizing the outdoor fan.

The defrost control will also energize auxiliary heat for increased comfort during defrost. The unit will remain in defrost until the defrost sensor has determined that the frost has been removed from the coil or a 14-minute time period has elapsed.

The defrost control is also equipped with a set of pins to aid in the troubleshooting of the defrost system (see Figure 9). The following is a brief outline of the testing of the defrost system.

1. Defrost sensor must be closed, 32°F or below. If temperatures are such that the switch will not close, jumper between defrost sensor terminals on the defrost control.
2. Start system in heating operation.
3. Place the defrost pin jumper on the test pins for a brief second, then place back on the proper defrost time setting (30, 60, or 90). This will speed up defrost time interval as shown in Table 7.

Defrost Control Setting	Defrost Test Cycle Time
30 minutes	7 seconds
60 minutes	14 seconds
90 minutes	21 seconds

Table 7. Defrost Test Cycle Time

The reversing valve will then shift to defrost mode and the outdoor fan should stop. After 2 seconds of defrost operation, the reversing valve should shift back to heating operation and the outdoor fan should start.

Diagnostic LEDs

The state (Off, On, Flashing) of two LEDs on the defrost board (DS1 [Red] and DS2 [Green]) indicate diagnostics conditions that are described in Table 8.

Mode	Green LED (DS2)	Red LED (DS1)
No power to control	Off	Off
Normal operation / power to control	Simultaneous slow flash	
Timed lockout	Alternating slow flash	
Low pressure switch fault	Off	Slow flash
Low pressure switch lockout	Off	On
High pressure switch fault	Slow flash	Off
High pressure switch lockout	On	Off

Table 8.

Maintenance

WARNING

Disconnect all electrical power to the unit before conducting any maintenance procedures. Failure to disconnect the power could result in personal injury or death.

Periodic inspection and maintenance normally consists of changing or cleaning filters and (under some conditions) cleaning the coils.

Filter

Inspect the filter once a month. Replace disposable filter or clean the washable filter as necessary (a minimum of three times each heating or cooling season is recommended).

To clean the washable filter, shake filter to remove excess dirt and/or use a vacuum cleaner. Wash filter in soap or detergent water and replace after filter is dry. It is not necessary to oil the filter after washing.

Motors

The indoor and outdoor fan motors are permanently lubricated and require no maintenance.

Outdoor Coil

Foreign material should not be allowed to accumulate on the outdoor coil surface or other parts in the air circuit. Cleaning should be as often as necessary to keep the coil clean. To clean the coil, remove the lower access panel and blow out debris by using compressed air or water. **Be sure power to unit is shut off before using water to clean the coil.**

Care should be used when cleaning the coils so that the coil fins are not damaged.

Outdoor Base Drain

Foreign material should not be allowed to clog the drain hole. Inspect and clear drain opening prior to heating season.

Accessories

Accessory		Nomenclature	Magic-Pak Unit					
			*MHP4-11-091*P	*MHP4-11-121*P	*MHP4-11-181*P	*MHP4-11-241*P	*MHP4-11-301*P	*MHP4-11-361*P
Polypropylene Louvers	Polypropylene Louver Kit - White (29" Height)	ALVRPWHT-1	•	•	•			
	Polypropylene Louver Kit - White (33" Height)	ALVRPWHT-2	•	•	•	•	•	
	Polypropylene Louver Kit - Sandstone (29" Height)	ALVRPSAN-1	•	•	•			
	Polypropylene Louver Kit - Sandstone (33" Height)	ALVRPSAN-2	•	•	•	•	•	
	Polypropylene Louver Kit - Beige (29" Height)	ALVRPBGE-1	•	•	•			
	Polypropylene Louver Kit - Beige (33" Height)	ALVRPBGE-2	•	•	•	•	•	
	Polypropylene Louver Kit - Taupestone (29" Height)	ALVRPTPST-1	•	•	•			
	Polypropylene Louver Kit - Taupestone (33" Height)	ALVRPTPST-2	•	•	•	•	•	
Aluminum Louvers	Extruded Aluminum Louver Kit (29" Height)	ALVRAL-1	•	•	•			
	Extruded Aluminum Louver Kit - Custom Color (29" Height)	ALVRAL-1P	•	•	•			
	Extruded Aluminum Louver Kit (33" Height)	ALVRAL-2	•	•	•	•	•	
	Extruded Aluminum Louver Kit - Custom Color (33" Height)	ALVRAL-2P	•	•	•	•	•	
	Extruded Aluminum Louver Kit (45" Height)	ALVRAL-3	•	•	•			
	Extruded Aluminum Louver Kit - Custom Color (45" Height)	ALVRAL-3P	•	•	•			
	Extruded Aluminum Louver Kit (45" Height)	ALVRAL-4				•	•	•
	Extruded Aluminum Louver Kit - Custom Color (45" Height)	ALVRAL-4P				•	•	•
Impact Rated Louvers	Extruded Aluminum Louver Kit - Impact Rated (29" Height)	ALVRALC-1	•	•	•			
	Extruded Aluminum Louver Kit - Impact Rated / Custom Color (29" Height)	ALVRALC-1P	•	•	•			
	Extruded Aluminum Louver Kit - Impact Rated (33" Height)	ALVRALC-2	•	•	•	•	•	
	Extruded Aluminum Louver Kit - Impact Rated / Custom Color (33" Height)	ALVRALC-2P	•	•	•	•	•	
	Extruded Aluminum Louver Kit - Impact Rated (45" Height)	ALVRALC-3	•	•	•			
	Extruded Aluminum Louver Kit - Impact Rated / Custom Color (45" Height)	ALVRALC-3P	•	•	•			
	Extruded Aluminum Louver Kit - Impact Rated (45" Height)	ALVRALC-4				•	•	•
	Extruded Aluminum Louver Kit - Impact Rated / Custom Color (45" Height)	ALVRALC-4P				•	•	•

Table 9. Accessories

Wall Sleeve		Nomenclature	Magic-Pak Unit						Dimensions (in)				
			*MHP4-11-091*P	*MHP4-11-121*P	*MHP4-11-181*P	*MHP4-11-241*P	*MHP4-11-301*P	*MHP4-11-361*P	A	B	C	D	E
6" Wall Sleeve Kit	for 29" Louver	ASLEEVE6-1	•	•	•				6	29	16	16-5/8	29-1/8
	for 33" Louver	ASLEEVE6-2	•	•	•	•	•		6	32-3/4	16	16-5/8	32-7/8
	for 45" Louver	ASLEEVE6-5	•	•	•	•	•	•	6	45	16	16-5/8	45-1/8
8" Wall Sleeve Kit	for 29" Louver	ASLEEVE8-1	•	•	•				8	29	16	16-5/8	29-1/8
	for 33" Louver	ASLEEVE8-2	•	•	•	•	•		8	32-3/4	16	16-5/8	32-7/8
	for 45" Louver	ASLEEVE8-5	•	•	•	•	•	•	8	45	16	16-5/8	45-1/8
10" Wall Sleeve Kit	for 29" Louver	ASLEEVE10-1	•	•	•				10	29	16	16-5/8	29-1/8
	for 33" Louver	ASLEEVE10-2	•	•	•	•	•		10	32-3/4	16	16-5/8	32-7/8
	for 45" Louver	ASLEEVE10-5	•	•	•	•	•	•	10	45	16	16-5/8	45-1/8
12" Wall Sleeve Kit	for 29" Louver	ASLEEVE12-1	•	•	•				12	29	16	16-5/8	29-1/8
	for 33" Louver	ASLEEVE12-2	•	•	•	•	•		12	32-3/4	16	16-5/8	32-7/8
	for 45" Louver	ASLEEVE12-5	•	•	•	•	•	•	12	45	16	16-5/8	45-1/8
Thru-The-Wall-Sleeve-Kit		ASLEEVE-3	•	•					N/A	45	16	16-5/8	45-1/8

Table 10. Wall Sleeves




Figure 10.

⚠ WARNING

The unit must be installed with approved wall sleeve and grille accessories for safe operation. Improper installations could result in property damage, personal injury, or death.

Wiring Diagrams





Figure 11. Connection Diagram - MHP With Single Circuit and Hard Start Enabled

